## Adjusting an **ECU®** PMTN

## **Adjusting Base timer**

This fine adjusts the timer

Turn the adjustment 30 turns counter clockwise. The pot has an overrun clutch to eliminate damage. Turn the pot 3 turns clockwise which should put the setting at about 0. When used in conjunction with the time multiplication of the system (see DIP switch adjust) various times from seconds to about 30 minutes can be achieved. Each turn clockwise will increase the time delay.

